PUBLISHED


B. GEHMLICH

Serial No. 365,903

MAY 4, 1943.

PHOTOGRAPHIC SHUTTERS

BY A. P. C. Filed Nov. 16, 1940



## ALIEN PROPERTY CUSTODIAN

## PHOTOGRAPHIC SHUTTERS

Bruno Gehmlich, Freital 1, near Dresden, Germany; vested in the Alien Property Custodian

Application filed November 16, 1940

The invention relates to improvements in photographic shutters and particularly is directed to curtain shutters, also known as focal plane shutters.

It is an object of the invention to provide a 5 photographic curtain shutter with a delayed action release which is released by an element of the certain shutter when the latter starts its movement to expose the film.

Another object of the invention is to provide 10 the roller on which the curtain tape is wound during the tensioning of the shutter with a camlike member which when the shutter is released and starts its exposure movement engages a control lever associated with the delayed action release and thereby causes the control lever to release the delayed action release. The control lever prevent a further motion of the shutter until the delayed action release has run off, whereupon the curtain resumes its movement 20 and exposes the film.

In the drawing:

Fig. 1 illustrates diagrammatically a curtain shutter provided with a delayed action release, the latter being shown in an untensioned posi- 25 tion.

Fig. 2 illustrates the curtain shutter with the delayed action release in a tensioned position, and

Fig. 3 illustrates the curtain shutter with the 30 delayed action release during the unwinding movement.

In the drawing, the curtain shutter I is provided with a cam 3 on the conventional roller 2 which takes up the curtain tape during the tensioning of the shutter. A control lever 4 on one hand is adapted to stop under certain conditions, as will be explained presently, the rotation of the roller 2 and on the other hand is adapted to lock the anchor-escapement of the delayed action 40 release against operation. The control lever 4 is slidably and pivotally supported by means of a fixedly mounted pin 5, which traverses a slot 8 in the lever 4 between the ends thereof. A spring 7 normally urges the control lever 4 upwardly toward the cam 3. The control lever 4 is provided with three lateral projections 8, 9 and 10 as shown. The delayed action release is provided with an anchor-escapement comprising the oscillatable anchor !! and the toothed wheel !2. A lever 13, which is usually mounted on the outside of the camera casing, is adapted to be manually rotated in one direction to tension the delayed action release. The lever 13 is attached to a shaft 20 on which a gear 15 is mounted. A pin 55 14 on one side of the gear 15 is adapted to engage the lateral projection 10 at the lower end of the control lever 4 and thus limits the unwinding movement of the delay action release. A spring 19 normally has the tendency to rotate the gear 15 in anticlockwise direction until it engages in the untensioned position (Fig. 1) of the delayed

action release the lateral projection 10 of the lever 4.

The delayed action release is tensioned by manually rotating the lever 13 in clockwise direction. When the pin 14 is thus moved away from the lateral projection 10 of the control lever 4. the spring 7 pulls the entire control lever 4 substantially lengthwise upwardly until the lower end of the slot 8 rests against the supporting pin 5. In this position of the control lever 4, as illustrated in Fig. 2, its lateral projection 9 engages the anchor if of the escapement and holds it in a position to prevent an unwinding of the tensioned delayed action release. At the same time the lateral projection 8 at the uppermost end of the control lever 4 comes to lie under the shoulder 32 of the cam 3, provided the curtain shutter is in a tensioned position. In this position of the parts. as illustrated in Fig. 2, a continuous unwinding movement of the shutter to expose the film in the focal plane of the camera cannot take place until the delayed action release has previously been run off.

When the shutter is caused to unwind, by depressing the conventional shutter release knob. the roller 2 starts to rotate in clockwise direction and the shoulder 3° of the cam 3 pushes the control lever 4 lengthwise downwardly a distance limited by the upper end of the slot 6. During this movement of the control lever 4, as illustrated in Fig. 3, the lateral projection 9 is moved away from the anchor ! and the latter is free to oscillate back and forth so as to control in well known manner the unwinding of the delayed 35 action release. During this unwinding movement the pin 14 on the gear 15 engages the lower end of the control lever 4 and rotates the same about its pivot 5 in clockwise direction. This has the result that the lateral projection 8 of the control lever 4 is moved away from the shoulder 3ª of the cam 3 and as soon as the cam 3 is thus released the shutter continues and completes its exposure movement and exposes the film in the focal plane of the camera. The unwinding move-45 ment of the delayed action release is completed when the pin 14 on the gear 15 engages the lateral projection io of control lever as shown in Fig. 1.

The cam 3 is so arranged on the roller 2 that in the unwound or released position of the shutter the highest point of the cam 3 projects into the path of lateral extension 8 of the control lever 4. Under this condition, the control lever 4 can not lock the anchor 11 of the escapement against movement when the delayed action release is tensioned without a prior tensioning of the shutter and the delayed action release would immediately begin its unwinding movement as soon as the operator releases the manually operable tensioning lever 13.